

- 28 -

LINEAR OPTICAL SAMPLING METHODS AND APPARATUS

ABSTRACT

An optical data signal can be sampled by linearly combining the optical data
5 signal with optical sampling pulses, and delivering the combination to first and second
balanced detectors. The optical data signal and the optical sampling pulse are
configured to have a first phase difference at the first balanced detector and a second
phase difference at the second balanced detector. Typically, a difference between the
first phase difference and the second phase difference is configured to be about 90
10 degrees. In-phase and quadrature balanced detector outputs can be combined as a sum
of squares to produce a linear sampling signal representative of data signal intensity,
and the sample pulses can be configured to temporally step through the optical data
signal so that a sampled representation of the optical data signal is obtained.